



## ELECTROCENTRALE BUCUREȘTI S.A.

Splaiul Independenței nr. 227, cod poștal 060041, sector 6, București  
Tel.: +4021.275.11.03, Fax: +4021.275.14.05  
office@elcen.ro, www.elcen.ro  
C.U.I.: 15189596, R.C.: J40/1696/2003



Nr.....

18795/15.06.2023.

**In atentie:** posibili ofertanti

**Referitor:** clarificare solicitata la documentatia de atribuire privind achizitia "Piese de schimb sistem de preparare si dozare solutie lapte de var nr.1-CTE Sud"

La solicitarea unui posibil ofertant, va transmitem raspunsul la urmatoarea solicitare de clarificare:

**Intrebare 1:** "Va rugam sa ne indicati seriile pompelor de dozare ALLDOS- GRUNDFOSS pentru care se solicita piesele de schimb conform CS 69/2023. "

Raspuns: Anexat va transmitem poza cu placuta de identificare a sistemului de preparare si dozare solutie lapte var.

**Director Juridic și Achiziții**

**Mihai VOLF**

Sef Serviciu Achizitii

Roxana Kedei

Sef BMAP

Anca Ordean

Responsabil achizitie

Andreea Tudor



Grundfos Water Treatment GmbH

Reetzstraße 85  
D-76327 Pfinztal (Söllingen)  
Phone (+49) 07240 61-0  
Fax (+49) 07240 61-177  
gwt@grundfos.com

Lime milk  
preparation system



Type: KD440-1020-T1-P1-C1-Z4-W1-D4441  
Part-No.: 99771718  
Capacity: 1000 l/h  
Supply voltage: 400V, 50Hz  
Power: 1,00 kW  
Order data: 2019 / 12427904  
Year of manufacture: 00 / 2020

ACHTUNG! Die Anlage ist vor UV-Strahlung zu schützen. Sie darf nur geschützt und trocken bei Temperaturen zwischen -5 und +50 °C gelagert werden.

CAUTION! Protect equipment against direct sunlight. Make sure it is protected and stored in dry area with temperature between -5 and +50 °C.

CAUTION! Protéger l'équipement contre les rayons directs du soleil. Conservation et stockage uniquement dans un endroit sec avec températures ne dépassant -5 et +50 °C.

ВНИМАНИЕ! Оберегать установку от прямого воздействия солнечных лучей. Хранить и устанавливать в сухом помещении при температурах от -5 до +50 °C.

WARNING! Bei laufenden Rührwerken und Trockengutdosierern nicht in die beweglichen Teile greifen. VERLETZUNGSGEFÄHR!

WARNING! Do not reach into the chamber and the hopper when the agitators or dry material hoppers are running. DANGER OF INJURIES!

ATTENTION! Ne pas intervenir à l'intérieur des cuves et dans la trémie de dosage lorsque les agitateurs ou les doseurs sont en fonctionnement.

ОСТОЖИТЕСЬ! Не вмешивайтесь во внутренности камер и бункера дозатора, когда работают мешалки и дозаторы. ОПАСНОСТЬ ТРАВМ!